KIDS watch Quick Start Guide

Please read the instruction manual carefully before you use it so that the correct installation and quick use can be made!

1. Preparation before using.

(1)Check all the accessories if they are complete.

(2)Choose the Nano-SIM card which match to the GSM network, you can refer to opinions of the dealer.(Power off before you insert the Nano-SIM card)

(3)The Nano-SIM card need to open the GPRS function and call screening function.

(4)Install the APP on the phone,you can ask the dealer if you don't know how to download it.

(5)The bar code and QR code is used to registered users.

2. Watch introduction

SIM card solt
USB Interface
Speaker
Puzzle park
Back
ON/OFF
SOS button
Microphone
diaL
C amera

back
Answer call

Part of the button function:

reset: reset after the need to power,

the light switch: continuous short press two times, open the lighting, and then press the button once, turn off the lighting

3. Product functions:

diaL	Phone book	Puzzle park	Micro chat	C amera
Album	APP downLoad	Mole Buildin	Ninja Running	God of Weath
Brave Monkey	Math Game			

LBS base station,Dial,SOS emergency alarm

4 Setup apn for access to GPRS network

SIM card in some countries need to setup apn before access to GPRS network, please contact the SIM card operator or check the website of the SIM card supplier for the apn information.

	Command	Example	Reply SMS
Setup APN	pw,123456,apn,apn name,user name,password,MCCMNC#	apn name=wap.tmobil.cl, user name=wap, password=wap, MCC=730, MNC=02, then the SMS command will be: pw,123456,apn,wap.tmobil.cl,wap,wap,73002#	apn:wap.tmobil.cl;user:wap;passwork:wap;userdata:73002.

Noet:If you insert the correct SIM and device online in the APP, no need set apn IP and port commands