

Kids Smart Watch

User Manual



Please read the instruction before installing and using the watch. Product color in kind prevails!

1. User Instructions

- a. Check if the device is the correct model with complete accessories: 1*GPS Watch with silicon wristband, 1* magnetic USB cable, 1*User manual, 1*toolkit (Screws and screwdriver).
- b. SIM Card: This model uses Nano SIM card which supports GSM network (2G). The card must enable GPRS data and caller ID function, 30 MB data per month will be enough.
- c. Turn off the watch before installing the SIM card.
- d. Charge the battery with matched charger. Do not charge over 2 hours.

Note: Charging the battery should only be under adult supervision.

e. Please scan the barcode (find at the last page) to download the APP Setracker.

2. Watch interface



This picture is for reference.

2.1 Product function


- GPS+LBS+AGPS+WIFI real-time Positioning
- 1.3 inch color touch screen (IPS)
- Footprints: record history route
- Records of step
- Sound guardian: Once the phone number confirmed via APP, watch will call the number automatically.

- Two-way phone call and voice chat
- IPX7 waterproof
- APP available for IOS and Android Platform
- Support no disturbing time when kids on class
- GEO fence
- SOS Phone call and alert
- Low power alarm
- Remote shutdown

Note: Do not wear the watch swimming, or taking shower.

3. Watch user interface


3.1 Main interface: Small icons on the interface top left to right represents: GSM signal, Location, Network, Battery status, the following is Time, Date, and number of Love icon.




3.2 Dial: **It** supports dial any other phone number even without **storing** in Phone book.



3.3 Phone book: Click and enter to set 10 phone numbers by APP, and pick number to dial.




3.4 Talk: Long press the button to record voice message and release to send to APP, the longest voice message can be recorded 15 seconds.




3.5 Step: Pedometer is off by default, it can be turned on via APP.


When pedometer is working, number of steps will be sync.



3.6 Device info: Click the QR code button then use mobile phone to scan the QR code to download the APP.



3.7 Camera: support shooting and store in device.



Note: There will be saved only one picture in the device. After you save the second picture, the old picture will be deleted automatically.