

GPS Pet Tracker Quick Start Guide



Please read the instruction carefully before use, so as to use quickly. Product appearance and color is subject to material object!

I. Product Function

- GPS + LBS +WIFI multiple Tracker
- Remote call
- Remote recording
- Electronic fence
- Historical track
- Sound-light pet finding
- Feeding reminder
- Low power alert
- Sports step counting

II. Sketch Map of Appearance



III. SIM Card Installation and Power-on

- #### 3.1 SIM Card Selection Requirements:
- Please use 2G-GSM network SIM card.
 - Terminal SIM card should enable caller ID function.
 - Terminal SIM card should enable GPS traffic.
 - code of terminal SIM card is in off state.

3.2 SIM Card Installation

•In power-off state, install Micro SIM card in the device according to the direction prompted by the SIM card as shown in the drawing below; it is suggested selecting (2G-GSM)30M data plan.
As shown in the drawing:



Card core faces to back of the device.

Notes: Tighten the screw of SIM card; don't miss the installation of waterproof silicone ring of screw.

3.3 Power on the Device

•Long press Power-on Key, after indicator light is lit with power-on sound, let go the key, the device enters Power-on state. (The device can't power off when it is online in APP client, only can remotely power off through APP client.)

IV. Explanation of Indicator Light

•Charging: When main unit is charging, LED indicator light is always on. When it is fully charged, LED indicator light is off.
•Power on: LED indicator light is lit for 3 seconds.
•Power-on recognition: In power-on state, press Power-on Key and indicator light is lit for 2 seconds.
•Abnormality: Connect to the server abnormally, indicator light is flashed slowly.

V. APP Using Steps

5.1 Download APP

Scan the following QR code to download Android and IOS client (please select Se-Tracker).



5.2 APP Account Number Registration

•Account number registration: Scan 15-digit registration code

or manually input the registration code to do registration. Registration code is unique, registration can't be repeated.



FAQ:

- ①Registration code has been used; it can be reused after being restored.
 - ②Account number has been registered, you should change the account number or restore such account number.
 - ③Retrieve password: Click Forget Password, input E-mail, click Send, and then input the verification code received from E-mail, operate according to the prompts.
- ### 5.3 Introduction to Main Interface Function
- #### 5.3.1 Interface of APP Function Menu

After completing the registration, enter correct account number and password in the login interface; click Login to enter into main interface.



Explanation to some functions of homepage:

•**Track:** Inquire about the historical track of the device according to time period. Base station switch of such interface is the switch for displaying the base station position point when inquires about the track; turn off the switch, the track doesn't display the base station positioning point; turn on the switch, it displays the base station positioning point.

- Voice Call:** Turn on voice call, push to talk, record 15 seconds and send to the device, the device will automatically play the record for the pet, also can dial the mobile phone number of the device for shouting at and calling the pets.
- Map:** View the device position in real time.



Map interface can display the position of all the devices and app mobile phone, can switch to the current device; click "positioning", the device begins to fix position for 3 minutes; upload interval is 20 seconds, it returns to the default operating mode after 3 minutes. In the map interface, you can know the

positioning mode of device in real time. When the positioning icon is red, it is gps positioning; when the icon is blue, it is base station positioning; when the icon is green, it is wifi positioning, i.e. network positioning.

•**Safety Zone:** Minimum radius of fence is 200 meters; when the user comes from inside of the fence to outside and gps fixes position, it would give an alarm out of fence.



•**Settings:** Set up various parameters of the device.
①**Phone Book:** More telephone numbers for dialing the device (white list).

②**Voice Monitoring:** Enter your mobile phone number, click Confirm; the device would dial your number, you can hear the surrounding voice status of the device; the device can't hear the voice status of mobile phone.

③**Work Mode:** Three work modes can be set up according to needs; follow-me mode is generally used in an emergency; power saving mode or normal mode can be selected according to own needs in normal times.

④**SMS Alert Settings:** SMS switch of low battery alarm

⑤**Feeding Reminder:** Set up three feeding reminding time. When time is up, the device will make a noise to remind you and pet.

⑥**Sound-light pet finding:** When you are walking the dog outside in the dark, operate the instruction, the device will prompt the pet location using sound and flashlight.

⑦**Remote Recording:** When you want to know the surrounding voice condition of pet, operate the instruction; the device will automatically record 15 seconds and send to mobile client.

•**Information Center:** Click to view the alarm information of the device.
•**Other Functions:** You can click the icon to know.

VI. Questions and Answers

•When mobile phone dials the device and prompts "the subscriber you dialed is busy now", it means that SIM card of device can't identify the number when caller ID is not enabled. Please enable caller ID of SIM card of the device.

•Can't connect to the service during the first power-on, APP issues instructions for showing that the device is off line.

①Check whether SIM card of the device is GSM network, for example, the network doesn't support China Telecom.

②Check whether SIM card of the device enables data traffic, must be compatible with 2g data traffic. The device only can use 2g data traffic now.

③Check whether server parameters (IP and port, ID) are correct, must guarantee that inquired ID number is consistent with ID number of APP device list; the customer can edit SMS pw,123456, using own mobile phone and send to the device for viewing the device parameters (the device must install the card and power on, SMS must be edited using English input method).

④Please edit SMS "pw,123456,apn, network name" using your mobile phone and send to SIM card number of the device; set up APN parameters of SIM card.